

Corner Guards

Koroseal Interior Products

Korogard® Stainless Steel Corner Guard

Recommended Installation Equipment: Drill/Screwgun and Screw Bit, or Mastic Construction Adhesive such as PL® Premium Heavy Duty Adhesive.

1. **Korogard®** Stainless Steel Corner Guards are supplied in specified lengths and with attachment screw holes as specified. A peel-off plastic coating protects the finished face of the Corner Guards.
2. Check material for compliance with Project Specifications and for any damage that may have occurred during shipment and/or handling at job site.
3. In accordance with facility architectural drawings and specifications, locate and install **Korogard** Corner Guards per the appropriate location drawing(s).
4. The wall surface where the Corner Guards are to be applied must be dry and free of contaminants.
5. Determine if you will install using cement or if you will screw on the Corner Guards.

Cement-On Installation:

- A. Apply construction adhesive in a zig-zag pattern over the back surface of each wing of the Corner Guard.
- B. Position Corner Guard on the wall appropriately and apply pressure along entire height until a tight and secure fit is achieved.
- C. Remove the protective plastic coating from the face of the Corner Guard.

Screw-On Installation:

- A. Attach Corner Guard to wall with specified attachment hardware (supplied by others).
- B. Remove the protective plastic coating from the face of the Corner Guard.
6. Clean with dry or slightly damp cloth as necessary.
7. If you have any questions during installation, please contact your local **Koroseal** representative.

KOROSEAL
Interior Products, LLC

800-628-0449 • www.korogard.com • Division 10 26 00

Korogard® is a registered trademark of Koroseal Interior Products, LLC.
PL® Premium Heavy Duty Adhesive is a registered trademark of Henkel Corporation.