

Corner Guards

KOROSEAL Wall Protection Systems **Korogard® Stainless Steel Corner Guard**

Recommended Installation Equipment: Drill/Screwgun and Screw Bit, or Mastic Construction Adhesive such as PL® Premium Heavy Duty Adhesive.

1. **Korogard®** Stainless Steel Corner Guards are supplied in specified lengths and with attachment screw holes as specified. A peel-off plastic coating protects the finished face of the corner guards.
2. Check material for compliance with Project Specifications and for any damage that may have occurred during shipment and/or handling at job site.
3. In accordance with facility architectural drawings and specifications, locate and install **Korogard** Corner Guards per the appropriate location drawing(s).
4. The wall surface where the corner guards are to be applied must be dry and free of contaminants.

Cement-On Installation:

- 5a. Apply construction adhesive in a zig-zag pattern over the back surface of each wing of the corner guard.
- 5b. Position corner guard on the wall appropriately and apply pressure along entire height until a tight and secure fit is achieved.
- 5c. Remove the protective plastic coating from the face of the corner guard.

Screw-On Installation:

- 6a. Attach corner guard to wall with specified attachment hardware (supplied by others).
- 6b. Remove the protective plastic coating from the face of the corner guard.
7. Clean with dry or slightly damp cloth as necessary.
8. If you have any questions during installation, please contact your local **Korogard** representative.

