

Corner Guards

KOROSEAL Wall Protection Systems

Korogard® R100, R400, & R410 Recess-Mounted Corner Guard

1. Cut retainer (with base attached) to full height. Install optional top cap clinching in place at top of retainer. Attach continuous retainer unit to corner using appropriate fasteners at 18" (457.2mm) O.C. maximum.
2. Finish walls to specification, taping and spackling over retainer flanges. Install wallcovering or paint as specified.
3. Snap precut **Korogard®** cover in position. Cover should be lipped over one edge and pressure applied toward opposite leg from center with a "snap action" movement. Procedure should begin at bottom and be repeated as necessary for full height of cover.

