

Technical Bulletin

Installation Tools / Supplies List Self-Adhesive Backed Material

- Scraper (to remove any tape or other surface imperfections)
- Mineral Spirits (for cleaning substrate)
- Step Ladder
- Slotted & Phillips Screw Drivers (to remove items such as frame)
- Auto Body Filler or Vinyl Spackle
- Medium & Fine Grit Sandpaper
- Drop Cloths (one to cut material on & one to keep installation area clean)
- Enamel Spray Paint (similar in color to substrate - lightly spot prime patched areas)
- Bucket (with clean water)
- Clean Sponge
- Pencil
- Tape Measure
- 4' Straight Edge or Level
- Razor Knife (with multiple blades)
- Pressurized Spray Bottle (available at hardware stores)
- Clear Dishwashing Detergent
- Flexible Wallcovering Smoother
- Soft Clean Cloths (many)
- 6" Broad Knife (for finish trimming)

Wallcovering Backed Material

Requires the above listed (EXCEPT: Mineral Spirits, Enamel Spray Paint, Auto Body Filler, Pressurized Spray Bottle, and Dishwashing Detergent) and the following:

- Double-Cutting Tool (by Warner Tools or Advance Equipment Manufacturing Co.)
- Paint Roller (with 3/16" nap roller cover for primer and 1/2" nap for adhesive)
- Paint Pan (with disposable liners)
- Quality Acrylic Wallcovering Prep (Professional R-35 or similar for difficult to bond surfaces)
- Joint Compound or similar Patching Compound
- Adhesive (heavy-duty clay or clear, VOV for impervious surfaces)
- Chalk Line (use light color chalk such as white or yellow)
- Paint Brush
- Seam Roller
- Painter's Tape
- Level

