



Mechanically fasten with self-tapping drywall screws and/or adhere aluminum extrusion with construction adhesive or contact cement.



## j-cap installation instructions

[www.walltalkers.com](http://www.walltalkers.com)

**walltalkers**

**a division of Koroseal Interior Products, LLC**

3875 Embassy Parkway  
Fairlawn, OH 44333-8333  
Ph: 800.820.9255 • Fax: 330.688.7703

7075JCP1111 10/14