



HUSTLE

PHYSICAL SPECIFICATIONS

Abrasion Resistance: Up to 30,000 minimum cycles (cotton duck)

- Roll Size: 50 lineal yards
- Fabric Width: 54" untrimmed
- Finish: Protected by **Teflon**[®] fabric protector system by Dupont
- Backing: Acrylic latex
- Composition: 100% polyester

FLAMMABILITY SPECIFICATIONS

- Meets a Class A Flame Spread Rating in accordance with ASTM E-84
- Meets Vertical Burn requirements in accordance with NFPA-701
- Passes Corner Burn (NFPA 265, UBC 8-2)

TEST SPECIMEN	FLAME SPREAD RATE	SMOKE DEVELOPED FACTOR
Asbestos Cement Board	0	0
Red Oak Flooring	100	100
Fabric – over 5/8" type "X" gypsum	20	50

NOTE: The numerical flame spread rating and other test results referenced herein are not intended to reflect hazards presented by this or any other material under actual fire conditions.

PERFORMANCE SPECIFICATIONS

Performance Test	Textile Wallcovering Standard Requirement	Results
ASTM D-1682	50 lbs. minimum	Warp 50 lbs.
Tensile Strength (Grab)	50 lbs. minimum	Filling 50 lbs.
ASTM D-2261	6 lbs. minimum	Across warp 9 lbs.
Tear Strength (Tongue)	6 lbs. minimum	Across filling 9 lbs.
ASTM D-4034	25 lbs. minimum	Seamed across warp 50 lbs.
Resistance to yarn slippage at seams	25 lbs. minimum	Seamed across filling 50 lbs.
AATCC 8	Dry procedure Class 4 minimum	Class 4 (dry procedure)
Colorfastness to crocking	Wet procedure Class 3 minimum	Class 4 (wet procedure)
AATCC 16A	Class 4 minimum	Class 4 (40 hours)
Colorfastness to light 40 hours		

ANTI-MICROBIAL PROPERTIES:

Hustle is woven with 100% polyester which will not mildew, rot or support the growth of bacteria and is non-allergenic.

MAINTENANCE:

Hustle is easy to clean. Depending upon the extent of soilage, use traditional cleaning methods, i.e., washing, wiping, vacuuming. If promptly treated, most indelible stains can be removed by using selected cleaning agents with no damaging effect.

STATIC PROPERTIES:

Hustle is woven with 100% polyester which has low static properties.

INSTALLATION:

Be sure edges are even. Wall should be cleaned and primed before application. Apply a thin coating of heavy duty vinyl adhesive to the wall – not the fabric. Allow adhesive to become tacky. Apply material to wall. Be sure edges butt evenly. Roll fabric firmly.

More detailed wallcovering installation instructions are enclosed with every fabric shipment and should be carefully read prior to installation.