

HANGING INSTRUCTIONS FOR TEXTILE WALLCOVERINGS



PREPARE THE WALLCOVERING

Before cutting material, confirm the accuracy of the pattern, color, and yardage

Confirm that consecutive bolt numbers are being used and lot numbers are identical

Recommended wall preparation is best accomplished when the building temperature is 70 degrees prior to beginning work.

PREPARE THE WALL SURFACE

To prepare the surface properly, we recommend that you prime all surfaces with water based primer (Roman Pro 999). All surfaces must be clean, dry, smooth, and structurally sound. Existing wallcovering must be removed from the surface prior to installation.

APPLICATION OF WALLCOVERING - HANG DRY

Use of heavy-duty clear adhesive is recommended (Romans 838). It is not recommended to dilute adhesive with water.

Cut the lengths to size allowing extra for trimming at ceiling and skirting. Material must be precut to factory laminated backing. It is recommended to table trim and butt, using a new blade for each sheet. Arrange the lengths in sequence and number the back of each length with a pencil.

Do not reverse: hang all drops the same way. Apply the adhesive to the wall evenly using the manufacturers recommended roller.

Allow the adhesive to dry and tack up. Hang the first length, rolled up backwards with back to wall using a plumb line.

Using a plastic wallpaper applicator, smooth down the center of the wallpaper to push out the air. Next, smooth down at an angle towards the outer edges from either side of the center. Smooth together and press down on the edges, once again with a plastic smoother or roller.

Remove any adhesive residue immediately by dabbing with a damp microfiber cloth and clean water after hanging each strip and before the adhesive has dried.