

# 1" AND 2" TACK RAIL INSTALLATION INSTRUCTIONS

1. Inspect material upon receipt to verify quantity and quality (mounting hardware supplied by installer).
2. If cutting of the aluminum is required, a miter saw with a fine-tooth carbide tip blade is recommended.
3. Install aluminum extrusion first. Allow at least 3" of clearance from end of extrusion to inside corners, door/window frames, or other protrusions from wall surface. The clearance is required so the Tac-Wall may be inserted in through the end of the extrusion.
4. Attach end caps.

