

Recommended Installer Qualifications: Only those parties experienced in working with finished fine wood products should engage in installing Bellagard Sculpted Wall Panels

Recommended Installation Equipment: Tape Measure, Level, Chalk Line, Drill/Screwgun, Large Flat-Bladed Screwdriver, and Construction Adhesive

1. Bellagard Wall Panels are supplied in factory-fabricated panels per provided Layout Drawing(s). If necessary, each supplied panel will be marked with a unique identifier in accordance with the identifier assigned per the Drawing(s). A copy of the Drawing(s) is included with the product shipment for reference.
2. In accordance with facility architectural drawings and specifications, locate and install Bellagard Wall Panels per Layout Drawing(s) and other applicable facility location drawing(s).
3. Lay out work to be completed, including all component parts, along base of substrate (wall). Check material for any damage that may have occurred during shipment and/or handling at job site.
4. Establish a baseline at the proper location on substrate to ensure level installation.
Note: Chalk line and reference marks may be visible after installation and must be removed at clean-up.
5. Begin at one end of the installation. If there is a restricted end due to a corner, door frame, or other obstruction, begin at that end.
6. Apply construction adhesive in a thorough and good workmanlike manner.
7. Align first panel to the baseline. Install supplied WalldogTM anchors. Be sure to use each screw hole in each tab.
Note: DO NOT over-tighten Walldog anchors.
8. Align second panel to the baseline. Align tabs and slots and slide into place. Screw in place along the three other edges. Repeat this step for each panel.
Note: There will be a slight, even gap between the panels to allow for expansion.
9. Push the supplied Klick clips into each slot. Use either your thumb or a large, flat-blade screwdriver. Be careful if using the screwdriver to not damage the panel.
Note: DO NOT install Klick clips before mounting the panel to the wall.
10. Align wood trim pieces with Klick clips. Trim pieces may require cutting to length.
11. Use your palm to press the trim piece onto the Klick clips until there is a solid click.
12. Clean with dry or slightly damp cloth. Touch-up panel finish where needed using supplied touch-up paint. Dab a small amount with a brush and rub with a clean, dry cloth.
13. If there are any questions, please call your local Korogard representative.