

Installation Tools / Supplies

For Tac-Wall tackable wallcovering

- Tac-Wall installation video (Walltalkers Part # TACV)
- Step Ladder
- Heavy Pressure Roller (Korogard Part # R333 or similar)
- Round Edge Seam Roller (available through floor covering stores: Gundlach Part # 1-S or similar)
- 1/16" Square Notched Trowel (Korogard Part # T001 or similar)
- L910 Linoleum Adhesive
- (2) Utility Knives
- Straight Utility Blades
- Wide Throat Hooked Utility Blades
- Roofing Felt or Red Rosin Paper (for pattern making)
- 1' Carpenters Square
- 4' or 6' Straight Edge (available through floor covering stores: Crain Part # 334S and 334)
- Extension Dividers (available through floor covering stores: Gundlach Part # 206C or similar)
- Pencil
- Chalkline
- 25' Tape Measure
- Masking Tape
- Seam & Strip Cutter (Walltalkers Part # T103)
- Seam & Strip Cutter Replacement Straight Blades (Walltalkers Part # T536 or similar; holes in replacement blades must match alignment pins in cutter)
- 4' Level or Plumb
- Bucket of Clean Soapy Water
- Soft Clean Cloths (many)
- Mineral Spirits