# WOOD VENEER PANELS & SYSTEMS CARE & MAINTENANCE



Our Wood Veneer is a natural wood product, so it requires careful attention. When veneer is properly cared for, it will retain its natural beauty and provide many years of service. To maintain the quality, please follow the cleaning procedures outlined here.

## NORMAL CLEANING

- Dust regularly with a slightly damp, soft, line-free cloth.
- Wipe dry in the direction of the wood grain.
- Immediately clean spills with a soft, damp cloth.

## MONTHLY

- Clean the surface with a soft cloth dampened with a quality cleaner formulated for wood furniture.
- Wipe the surface in the direction of the wood grain to remove dirt and fingerprints.
- Wipe dry with a clean, dry cloth.

## EVERY SIX MONTHS

- Apply a good quality furniture polish with a soft cloth
- Avoid aerosol-powered cleaners, wax-based polishes, and oil-based polishes.
- Use a soft vacuum brush (non-bristle) to clean acoustic panels.

## STAINS

Our Wood Veneers are rigorously tested for resistance to wear, light, stains, water, and pressure. To reduce the risk of damage, take some precautions:

- Use coasters for glasses, mugs, and hot objects.
- Place felt pads under glass tops.
- Use watertight containers or drip trays for potted plants.
- Avoid prolonged contact with vinyl binders
- Use protective pads under equipment with rubber feet, as certain compounds may cause staining.

## MINOR REPAIR OF WATER RINGS, STAINS, AND SCRATCHES

- Lightly rub the surface in the direction of the wood grain using NO. 000 steel wool.
- Apply a scratch-removing polish that matches the veneer's color and finish.