
DAILY MAINTENANCE

Dust and Dirt

Dust and airborne particles may accumulate on the surface over time. Regular dusting with a duster or wiping with a soft cloth is recommended to maintain the appearance of the finish. Textured surfaces may collect dust more easily and should be cleaned periodically.

Routine Cleaning

For routine cleaning, wipe the surface with a soft cloth dampened with water or a diluted neutral detergent solution. After cleaning, remove any remaining detergent residue and moisture by wiping the surface dry with a clean, soft cloth.

Stain Removal

Most stains can be removed using a mild household cleaner and a soft cloth. For stubborn stains, spot cleaning with a diluted isopropyl alcohol (IPA) solution may be effective. Always test cleaning products in an inconspicuous area before use.

Cleaning Products to Avoid

Do not use abrasive cleaners, scouring pads, polishing compounds, or solvents such as lacquer thinner, acetone, MEK (methyl ethyl ketone), or toluene, as these may damage the surface finish or alter its appearance.

Long-Term Care

Regular cleaning and prompt removal of contaminants will help preserve the appearance and long-term performance of the finish. Dirt and contaminants that remain on the surface for extended periods may become more difficult to remove.

Moisture and Seams

Do not allow water, cleaning solutions, or disinfectants to remain on seams, edges, or joints for extended periods. Prolonged exposure to moisture may affect adhesion performance over time.

DISINFECTION

Disinfection Procedure

When disinfection is required, first clean the surface using soap and water or a neutral detergent solution. Selected EPA List N disinfectants and CDC-recommended diluted bleach solutions have been tested on REATEC with no evidence of discoloration or damage to the film surface. Follow the disinfectant manufacturer's instructions regarding dilution, application method, and contact time.

Tested Disinfectants

The following disinfectants have been tested on REATEC with no evidence of discoloration or damage to the film surface.

PRODUCT	ACTIVE INGREDIENT
Virex™ II 256	Quaternary Ammonium
Oxivir™ Tb	Hydrogen Peroxide
CaviCide®	Quaternary Ammonium
Wex-Cide I28	Isopropanol
Spray Nine®	Phenolic
Opti-Cide 3®	Quaternary Ammonium
Fantastik® All Purpose Cleaner	Quaternary Ammonium
CDC Diluted Bleach Solution	Sodium Hypochlorite

Important Notes

As with any cleaning or disinfecting product, testing in an inconspicuous area before broad application is recommended. Avoid prolonged exposure to concentrated chemicals and promptly remove any excess liquid from the surface after cleaning or disinfection.