



## **B200-Series Bumper Guard**

- 1. Locate and install Korogard Bumper Guard in accordance with architectural drawings and specifications. When required, Korogard shop drawings should be used in conjunction with these documents.
- 2. Lay out the work to be completed, including all component parts, along the base of the substrate (wall). Check the material for any damage that may have occurred during shipment and/or handling at the job site.
- 3. Snap a chalk line at the proper location on the substrate to ensure a level installation. Chalk line should be calculated to the center line of the wall fasteners.
- 4. Determine Bumper Guard end locations on substrate. Mark and cut aluminum retainer to appropriate length. Insert end caps and field-drill proper size holes along center of retainer 1/2" (12.7mm) in from each end (through the end cap flange and retainer) and at intermediate locations along the retainer not exceeding 32" (812.8mm) O.C.
- Place the retainer in the proper position on the chalk line and attach to wall with proper fasteners (not included).
  Note: Prior to installation of the Korogard vinyl insert, make sure that all fasteners are secure and properly seated.
- 6. Determine the distance from inside of end cap to inside of end cap. It is recommended that the vinyl insert be cut slightly oversize to provide tight fit at caps. Cut Korogard vinyl insert cleanly and squarely to appropriate length.
- 7. Hold the Korogard vinyl insert at an angle and place the top lip of the insert inside the retainer. Make sure that the insert is tight against the end cap and fit the Korogard insert to the retainer by pinching between fingers and applying pressure to force the insert into the retainer. Continue along until the complete length of the insert is securely installed.
- 8. If you have any questions during installation, please call your local Korogard representative





Installation Dimensions for B200-Series Bumper Guard



Model B200

