

# COMFORT ZONE WOOD ACCOUSTICAL CEILING PANEL INSTALLATION INSTRUCTIONS



These installation suggestions consist of a common process for Comfort Zone Wood installation. Installers should rely upon their own professional experience and understanding of their unique requirements to ensure a successful install.

Comfort Zone Wood will look best when installed with no gaps between ends or rows.

---

## Tools You Will Need:

Tape Measure  
Pencil  
Level

Drill  
Drywall Hoist Lift (Optional)  
Circular Saw

Hand Saw  
Utility Knife (with sharp blade)

---

## Materials You Will Need:

1.25" Black Drywall Screws  
Furring Strips (7/8" or 2" thickness recommended)

7/16" Drywall Screws  
Masking Tape

---

## Items Included:


Comfort Zone Wood




# COMFORT ZONE WOOD ACCOUSTICAL CEILING PANEL INSTALLATION INSTRUCTIONS



1. Start by preparing the ceiling. Clean the ceiling and remove any screws, nails and other obstacles. Measure the dimensions of the ceiling.




2. Create a framework by evenly spacing furring strips on ceiling every 24". The framework should point the opposite way of the Comfort Zone Wood direction. NOTE: The thicker the furring strips, the larger the air cavity, therefore increased sound absorption.



# COMFORT ZONE WOOD ACCOUSTICAL CEILING PANEL INSTALLATION INSTRUCTIONS




3. Position and secure Comfort Zone Wood to the furring strips on the ceiling with screws, placing them approximately every 16" to 24". TIP: If desired, use a drywall hoist to aid in completing this step.



**NOTE: Do NOT** place screws on the wooden portion of Comfort Zone Wood. Only place on the PET felt portion in between wooden strips.




Use the premade shi lap joint to maintain even spacing and to avoid visible seams.




# COMFORT ZONE WOOD ACCOUSTICAL CEILING PANEL INSTALLATION INSTRUCTIONS



4. Cut excess material to fit the ceiling or accommodate obstacles, if necessary. When cutting through PET, use box knife. When cutting through wood veneer, use handsaw or jigsaw. Use masking tape to prevent splintering or splitting.



After cuts are made, reattach the wooden slats to PET backing with .5" screws, working from the backside of the panel.




# COMFORT ZONE WOOD ACCOUSTICAL CEILING PANEL INSTALLATION INSTRUCTIONS



5. Repeat the process to install the rest of Comfort Zone Wood to the ceiling. Comfort Zone Wood will look best when installed with no gaps between ends or rows.

**TIP:** Spray paint electrical cover and the surrounding ceiling black prior to install to match.



# COMFORT ZONE WOOD ACCOUSTICAL CEILING PANEL INSTALLATION INSTRUCTIONS



---

## T-Grid Ceiling Installation Direct Install with Screws

These installation suggestions consist of a common process for Comfort Zone Wood installation. Installers should rely upon their own professional experience and understanding of their unique requirements to ensure a successful install.

NOTE: Check the T-Grid's weight capacity prior to install to confirm product selection. Comfort Zone Wood Panel: 35 lbs

Comfort Zone Wood will look best when installed with no gaps between ends or rows.

---

## Tools You Will Need:

Tape Measure  
Pencil  
Level

Drill  
Drywall Hoist Lift (Optional)  
Circular Saw

Hand Saw  
Utility Knife (with sharp blade)

---

## Materials You Will Need:

1.25" Black Drywall Screws  
Furring Strips (7/8" or 2" thickness recommended)

7/16" Drywall Screws  
Masking Tape

---

## Items Included:


Comfort Zone Wood




# COMFORT ZONE WOOD ACCOUSTICAL CEILING PANEL INSTALLATION INSTRUCTIONS




1. Measure the dimensions of the and remove all existing ceiling tiles.



2. Cut excess material to fit the ceiling or accommodate obstacles, if necessary. When cutting through PET, use box knife. When cutting through wood veneer, use handsaw or jigsaw. Use masking tape to prevent splintering or splitting.




After cuts are made, reattach the wooden slats to PET backing with .5" screws, working from the backside of the panel.



# COMFORT ZONE WOOD ACCOUSTICAL CEILING PANEL INSTALLATION INSTRUCTIONS




3. Position and secure Comfort Zone Wood on the ceiling T-Grid with screws, placing them approximately every 24 inches. Use 3/4" black head sheet metal screws. It is recommended a drywall brace or lift is used for this process.



**NOTE: Do NOT** place screws on the wooden portion of Comfort Zone Wood. Only place on the PET felt portion in between wooden strips.



Use the premade shi lap joint to maintain even spacing and to avoid visible seams.





## COMFORT ZONE WOOD ACCOUSTICAL CEILING PANEL INSTALLATION INSTRUCTIONS



4. Repeat the process to install the rest of Comfort Zone Wood to the ceiling. Comfort Zone Wood will look best when installed with no gaps between ends or rows.

**TIP:** Spray paint electrical cover and the surrounding ceiling black prior to install to match.

